


# TPD Series Manual



---

---

## TPD operating instructions

Foreword: We are very happy that you have chosen this car navigation audio and video products. This manual will systematically introduce the basic functions, usage skills and precautions of the car. Let new users quickly get to know, please read carefully before using, thank you!

### table of Contents |

The first module: basic knowledge

- 1.1 boot and shutdown instructions
- 1.2 screen function buttons
- 1.3 main interface and application interface
- 1.4 drop-down menu and status bar
- 1.5 wallpaper replacement
- 1.6 boot animation settings

### The second module: the main function

- 2.1 Navigation function
  - 2.1.1 Use of maps
  - 2.1.2 Map offline data copy and APK installation
  - 2.1.3 Selection of navigation path
  - 2.1.4 Navigation Startup
- 2.2 Radio function
- 2.3 Bluetooth function
  - 2.3.1 Paired devices
  - 2.3.2 Bluetooth music
  - 2.3.3 Bluetooth Address Book
  - 2.3.4 Dialing and Calling Features
- 2.4 Music

- 2.5 video
- 2.6 Equalizer (EQ)
- 2.7 AUX IN
- 2.8 Third Party Application - Yilian
  - 2.8.1 billion connected → Android USB
  - 2.8.2 billion connected → Android WiFi
  - 2.8.3 billion connected → iPhone

## **The third module: about settings**


- 3.1 WiFi settings
- 3.2 Sound settings
  - 3.2.1 Reversing mute
  - 3.2.2 Navigation channel
  - 3.2.3 Navigation volume
  - 3.2.4 Device ringtone
- 3.3 Date and time
- 3.4 Switching input method
- 3.5 Steering wheel learning






# basic knowledge

## 1.1 boot and shutdown


boot	Plug in the car key, turn on the ACC power, the device will automatically boot, display the boot LOGO animation
and shutdown	After removing the car key and turning off the ACC power, the device will automatically shut down.

## 1.2 screen function buttons



	Power	Power on state.Long press, system off screen Short press, mute
	Main interface	Press to return to the main interface
	return	Press to return to the previous interface and exit the current source
	Volume plus	Press volume up
	Volume reduction	Decrease the volume


## 1.3 main interface and application interface

- 1.This device has a multi-page screen, and slide to the left or right to switch between them.
- 2.Click the application icon  on the main interface to enter the application interface.



# 1.4 Status Bar and Drop-Down Menu Interface

The car status bar and drop down menu functions are as follows:




	WiFi		Suspension switch
	Bluetooth		menu
	Equalizer sound		Clean up memory
	Off screen		Screen capture
	Setting		Restart
	volume		brightness

# 1.5 wallpaper replacement



There are two ways to set the wallpaper:

- 1.When you press and hold in the blank space of the main interface, the “Select wallpaper source” box will pop up.
- 2.In Settings → Display → Wallpaper, choose the wallpaper source according to your personal preferences.



# 1.6 boot animation settings


- 1.application interface to open [boot animation], select an animation click to confirm the change
- 2.Custom animation: Copy the animation file in the root directory of the Scard or U disk of the car, click the “Menu button” in the drop-down bar to pop up: “Import from external storage” bar, pop up the password box, enter: Topway to import the animation in the U disk File, select and confirm Replacement



## The second module: the main function

### 2.1 navigation function

#### 2.1.1 Use of maps


main interface click navigation icon  or application interface click navigation function to enter the map interface





#### 2.1.2 Copying and installing maps

1. How to copy and install if the car has no map? The following IGO maps are given as examples

2. Copy the map package and APK to the SD card or USB flash drive (example copy on the USB flash drive)

3. Click  to enter the application interface, open [File Manager], the left directory can see the U disk path)





4. Enter the U disk, check the map data package and APK, click [Copy] in the lower left corner; switch to the "Local" directory, click [Paste] in the lower left corner. The copy is estimated to take 10 minutes. After the copy is complete, click on the map APK to install it.

### 2.1.3 Selection of navigation path

After copying the map offline data and installing the map APK, how to associate the navigation icons of the main interface?


Settings → Car Settings → Navigation Software, find the IGO map and click to select.



### 2.1.4 Navigation Startup

How to display the map interface after booting?

1. Settings→Car Settings→Navigation Startup, the default is off, set to open.
2. You must close the ACC on the map interface, otherwise will not enter the navigation interface.



## 2.2 Radio function

Click the radio function on the main interface or application interface to enter the radio interface:




	HOME button	DX	Remote/short range switching
	Storage station		Sound effect
	Low frequency sweep		return key
BAND	Band switching FM1/2		Low frequency stepping
	High frequency sweep		High frequency stepping

## 2.3 Bluetooth function

Click on the Bluetooth function to enter the Bluetooth interface

### 2.3.1 Paired devices

1. When you are not paired with the device, you can only enter the settings and search interface.
2. Pairing interface Click to find nearby devices, select the device to be paired, the phone will pop up the PIN code box, enter the PIN code , the icon indicates that the connection was successful.



### 2.3.2 Bluetooth music


Click the icon to enter the music player interface. After connecting with the phone, you can operate the [Play and Pause] and [Previous/Next] functions.










**Note:** Using the Bluetooth music function, the music player of some mobile phones needs to open the music page from the mobile phone first.

## 2.3.3 Bluetooth Address Book

1. Bluetooth interface click  to enter the address book interface

2. Download Step: Select Phone/SIM--Click the [Download] button to confirm the box synchronization address book request.



	Mobile phone book
	SIM card phone book
	Download button
	Delete all imported phonebooks





2 Find a contact: After synchronizing the address book, click the corresponding phone/SIM button. A search box pops up.

## 2.3.4 Dialing and Calling Features

### 2.3.4.1 Dialing function

Click  to enter the Bluetooth dialing interface and enter the number you want to dial.



1. Click on the number to enter the phone number, enter the error and click  to delete it bit by bit.  
2 After entering the number, click  Dial; 点按  ends the current call. When you are on a call,  switches to a mobile phone call.


2.3.4.2 Call function

When the mobile phone book/unfamiliar number is not downloaded, the caller can only display the phone number. After downloading, the contact name is displayed when the call is made.







**Note: The floating small window disappears automatically after the call ends.**

2.3.4.3 Call history

- 1.Click  to enter the call history interface, only the call history when pairing Bluetooth is synchronized.
- 2.call record interface, click the contact in the list to broadcast the call



	Missed call
	Received call
	dial number
	Delete call history

2.4 Music function

Click the music icon button to enter the music player interface.  
Select the playback path [Playlist], [SD Card], [U Disk], [Local] at the top of the interface.



	HOME button		Next song
	Random mode		Single/list loop
	Previous song		Sound effect
	Pause / resume playback		return key

## 2.5 Video function

Click the video function to enter the video playback interface.

The format supported by the video player is as follows:

MP4/AVI/WMV//MOV/MKV/MPEG/RMVB, etc.



	HOME button		Rewind
	Previous song		Fast forward
	Pause / resume playback		Full / small screen
	Next song		return key

## 2.6 Equalizer (EQ)

2.6.1 There are two ways to enter the EQ interface:

1.application interface, click to enter the equalizer setting

2.Click on the radio and music interface to enter the equalizer setting interface.

2.6.2 Classification: Equalizer and sound field settings

1.Equalizer settings with 8 sound effects to choose from



2.Sound field setting, the user can freely adjust the contrast of the bass and loudness, and adjust the volume of the front left, front right, rear left, rear right four directions.




## 2.7 Aux In function

Enter the AUX IN interface;

1.When the video input signal is not connected, the AUX IN interface displays: no video signal

2.access signal, AUX interface displays video screen,  returns to the previous interface,  returns to the main interface, timeout is hidden



## 2.8 2.8 Third Party Application - [EasyConnect]

Four functions of EasyConnect: Android USB/Android WiFi/iPhone USB/iPhone WiFi  
EasyConnect version: ;

**EasyConnect. TW12. 6. 1. 2-7233490-201910121553. release. apk**

Note: You need to activate before using EasyConnect, otherwise you can't use it; at the same time, the mobile phone also needs to download EasyConnect APP.

Mobile phone download EasyConnect way: EasyConnect home page - click "How to connect?" Follow the prompts to download



### 2.8.1 EasyConnect → Android USB use

1.Android EasyConnect sound is a Bluetooth channel. It is recommended to pair the Bluetooth device first, otherwise the sound will be output from the mobile terminal.

2.Connection steps: After entering EasyConnect, connect the mobile phone and the car through the USB data cable, EasyConnect will automatically detect and click the “Central Control Screen Pairing” application, click to confirm the connection. (Do not connect other devices during operation)



## 2.8.2 **EasyConnect** → use of Android WiFi

Android Yilian sound, you need to pair with Bluetooth devices.

**There are three states of WIFI connection:**

- 1.**Turn on the mobile data and hotspot switch, and connect the mobile phone hotspot (recommended)**
- 2.car and mobile phone connected to the same LAN
- 3.The Yilian application of the mobile phone, manual opening or automatic detection, the connection car will automatically detect the connection.

## 2.8.3 **EasyConnect**→ **iPhone**

- 1.Apple and Android are connected in the same way.
- 2.Apple billion sound independent, no need to pair Bluetooth. The default is the car output.
- 3.Apple opens the phone hotspot and supports mirroring

## The third module: about settings

### 3.1 WiFi

There are two ways to open and close WiFi:

- 1.drop-down menu WLAN function. Short press: Turn off/on switching. Long press: Enter the WLAN settings interface.
- 2.Settings→Network and Internet→WLAN

### 3.2 sound

The sound settings are mainly about four common functions: reversing mute, navigation channel, navigation volume and device ringtone.

**3.2.1 Reversing mute:** When checked, any mode reverses, the car has no sound output; when unchecked, there is sound output

**3.2.2 Navigation channel:** Prerequisites: Bind navigation, (Navigation software interface select map APK)

1.Front left and front right: When navigating, it is not a system sound source, such as radio/AUX/DVD/TV/external Bluetooth mode, navigation only outputs from the front left and front right, and the left and right rear keeps the sound of the current source;

2.All: When navigating, all four channels have navigation sounds.

#### 3.2.3 Navigation volume

1.Navigation: slide the progress bar, adjust the volume of the navigation, and then navigate after setting.


2.background music: slide the progress bar, adjust the current source sound size, adjust the size, reduce the current source sound when navigating; adjust to 0, insert the video when navigating, (the current source has no sound output when navigating the broadcast); The source sound is raised.

**3.2.4 Device ringtone:** music played when the car calls

### 3.3 Date and time


The device automatically calibrates the current time, manually setting the date, time, time zone, and format using the time and time zone provided by the network.

**Settings → System → Date and time, you can set the time zone and time format as needed**



3.4 switching input method

Settings → Language and Input Method → Virtual Keyboard → Manage Keyboard. The opening that will be used, the remaining is closed.



3.5 Steering wheel learning

Apply menu → steering wheel, the user can set according to the prompts.

The square control interface is only for models without the CAN protocol.


Learning steps:

- 1.First click the [Start] button.
- 2.Click on the button you need to learn.

3.Press the corresponding button on the steering wheel of your car. If the learning is successful, the buttons on the square control interface will have corresponding color changes.

4.Repeat steps 2 and 3. Until you finish setting all the buttons on the car's steering wheel.

5.Click [End] and the controller setting process ends.



**Note: If you want to relearn the steering wheel button, click [Start] and then click [Clear], then repeat steps 1, 2, and 3.**

At this point, the description is over, thanks for reading